



# Fluke PQ400 Electrical Measurement Window installation drawing



**Required space  
for cabinet outside**

**Required space  
for cabinet inside**

Consider space requirements  
for individual mounting  
postion/cable routing!



**Fluke.** *Keeping your world  
up and running.*®

**Fluke Corporation**  
PO Box 9090, Everett, WA 98206 U.S.A.

**Fluke Europe B.V.**  
PO Box 1186, 5602 BD  
Eindhoven, The Netherlands

**Modification of this document is not  
permitted without written permission  
from Fluke Corporation.**

**For more information call:**  
In the U.S.A. (800) 443-5853 or  
Fax (425) 446-5116  
In Europe/M-East/Africa +31 (0)40 267 5100 or  
Fax +31 (0)40 267 5222  
In Canada (800)-36-FLUKE or  
Fax (905) 890-6866  
From other countries +1 (425) 446-5500 or  
Fax +1 (425) 446-5116  
Web access: <http://www.fluke.com>

©2019 Fluke Corporation.  
Specifications subject to change without notice.  
7/2019 6012584a-en